

TOP 10 TIPS

To make your floor labels last!

Application

Floor preparation:

Sweep away dirt and debris, clean with a general cleaner, and allow the floor to dry completely before application.



Proper placement:

Don't apply over floor seams and joints, or on rough, uneven surfaces like asphalt.



Apply directly:

Avoid placing over floor tape or painted lines. Underlying layers can affect adhesion overtime.



Edge overlap:

Leave 1/2" of laminate beyond the label edges. This creates a tight seal, protecting against contaminants and abrasion.



Press firmly:

You can use your hand or foot to apply pressure, but a forklift leg works great and requires a little less muscle.



Bonding time:

Wait 48 hours before allowing forklifts, carts, or foot traffic on the new shield for optimal adhesion.



Maintenance and Use

Keep Clean



Keep warehouse floors tidy for longer lasting labels

Proper Operation



Don't drag pallets, protruding nails can damage floor labels

Adaptive Option



Easy to remove, simply peel off using a scrapper blade

Optimal Application



Match labels to their intended environment



Questions? Contact us today!

Visit barcode-labels.com or call 800.535.6987